


A: Remove brushes and wash with clean, warm water.

B: Replace brushes. Brushes must be angled toward the front of the dispenser.




A: Fill water tank with clean water

B: To avoid spilling, place finger over fill hole when returning full water tank to its holder




Adjust Water Level OPTIONAL STEP



A: If necessary, water level can be adjusted by turning the screw on the water tray





A: Pull knob to set desired tape length

B: Pull lever to dispense tape.

Need more help? Download the full manual or contact us

TDH₂O1








4270 Airborn Dr. Addison, TX 75001, USA 972.248.1999 | tech@startinternational.com

startinternational.com

TDH₂O1


Manual Gummed "Water Activated" Tape Dispenser

ITEMS INCLUDED




Dispenser






A: Open rear cover

B: Adjust reel guides to fit the tape roll




A: Insert tape roll and guide tape over the black lift roller and the metal guide bar



A: Raise front cover and continue feeding tape under the upper tape plate



Check Tape



A: Close lids and pull handle to dispense one piece of tape. This will ensure that the tape is loaded properly.